

PANNEAUX
VIZÜWALL
PANELS

Installation Guide

TOOLS REQUIRED

VIZÜWALL PANELS
Construction Wood Adhesive
Nail Gun & Finishing Nails
Measuring Tape
Masking Tape
Cutting Tools (if necessary)

INSTALLATION STEPS

- 1) Start by laying flat the VIZÜWALL panels in the room where they will be installed for at least 24 hours to let the panels acclimatize prior to installation.
- 2) Ensure all surfaces are clean and dry for an optimal installation.
- 3) Measure the wall surface and map out guidelines to follow so that the first panel is straight once installed on the wall.
- 4) Apply adhesive glue in a zig-zag pattern to the back of the panel. Be sure to leave at least 2 finger widths away from the edges to avoid excess glue flowing through joints of 2 adjoining panels.
- 5) Position the VIZÜWALL panel onto the wall, following your guidelines. Apply hand pressure to the panel where the adhesive is located. Be sure to start in the middle of the panel, working to the outer edges.
- 6) **Using your nail gun, reinforce the panel on the wall** (suggested: 9 nails per panel in regular intervals.) Also suggested to affix the nails through the MDF grooves of the panel at a 45° angle for optimal installation.
- 7) Repeat steps 4, 5, and 6 as needed until your space is covered.



TIPS

** When cutting your VIZÜWALL panels, place finished side up and use a saw with the proper finishing blade. Use masking tape to prevent splinting / chipping.

** VIZÜWALL panels are suitable for kitchen & bathroom installations if they are not in direct contact with water. Intended for indoor use only!

** Small paint touch-up can be applied to the top of nail heads once installed onto the wall (optional)

Distributed by



www.vizusolution.com