

INSTALLATION GUIDE

Installation Instructions for VIZÜWALL panels

1. Panel Acclimation

Before installation, lay the VIZÜWALL panels flat in the room for at least 24 hours to allow them to acclimate to the environment.

2. Surface Preparation

Ensure the surface is clean, dry, and free of dust or debris.

3. Measuring and Layout

Measure the wall area to be covered and draw guidelines to ensure the first panel is installed straight.

4. Adhesive Application

Apply construction adhesive to the back of the panel in a zigzag pattern. Leave at least a two-finger gap from the edges to prevent excess adhesive from seeping between panels.

5. Panel Installation

Place the panel on the wall following the guidelines. Press firmly from the centre outward to the edges to ensure proper adhesion.

6. Mechanical Fastening

Using a nail gun, reinforce adhesion with approximately 9 evenly spaced nails. Whenever possible, drive nails at a 45° angle through the MDF grooves for a discreet finish.

Repeat

Repeat steps 4 to 6 until the entire surface is covered.

Tips

When cutting VIZÜWALL panels, place them face up and use an appropriate finishing blade. Apply masking tape along the cut line to prevent scratches, splinters, and chipping.

VIZÜWALL panels are suitable for installation in a kitchen or bathroom, provided they are never in direct contact with water or steam. They are intended for indoor use only.

If needed, nail heads can be concealed using small paint touch-ups.

Materials and Tools Required:

- VIZÜWALL panels
- Construction adhesive or Dural panel adhesive (tube / thin beads application)
- Nail gun
- 1" or 1 1/2" finishing nails (18 gauge)
- Measuring tape
- Masking tape
- Saw (if required)

Distribué par



goodfellowinc.com

STRAF
EST. 1929

M400
ENDURA TAC

Quick Setting Repair & Mounting Adhesive,
300 ML.

Sold in boxes of 12 tubes.
711040026

